

SR Series

1KW Pure Sine Wave Power Inverter

User's Manual



CE FC

Contents

| | |
|--|----|
| 1. Important Safety Instructions | 3 |
| 1-1 General Safety Precautions..... | 3 |
| 1-2 Other Safety Notes..... | 3 |
| 2. Introduction to Functional Characteristics | 4 |
| 2-1 System..... | 4 |
| 2-2 Block Diagram..... | 5 |
| 2-3 Electrical Performance..... | 6 |
| 2-4 Mechanical Drawings..... | 7 |
| 3. Installation and Maintenance | 8 |
| 3-1 Rear Panel..... | 8 |
| 3-2 Front Panel..... | 14 |
| 3-3 Maintenance..... | 14 |
| 4. Operation | 14 |
| 4-1 Connecting the Input Power..... | 14 |
| 4-2 Connecting the loads..... | 14 |
| 4-3 Inverter Operation..... | 15 |
| 4-4 Protection Features..... | 15 |
| 5. Front LCD Panel - Display and Setup | 15 |
| 5-1 LCD Panel Indications..... | 15 |
| 5-2 Startup Sequence and Standby Status..... | 18 |
| 5-3 Setup Menu - Operation and Instructions..... | 18 |
| 6. RS232 Communication and operation | 23 |
| 6-1 Operation of RS-232 Serial Port..... | 23 |
| 6-2 Interface Commands..... | 24 |
| 6-3 Example of RS232 Operation..... | 25 |
| 7. Information | 29 |
| 7-1 Troubleshooting..... | 29 |
| 7-2 Warranty..... | 30 |

8. Appendices.....

8-1 FCC (Class B) Declaration of Conformity.....

8-2 EMC Declaration of Conformity.....

8-3 CE (LVD EN60950) Declaration of Conformity.....

8-4 UL (UL458) - Notice of Completion.....

1. Important Safety Instructions



WARNING!

SAVE THESE INSTRUCTIONS – This manual contains important instructions that should be followed during installation and maintenance of the inverter.

1-1. General Safety Precautions

- 1-1-1. Do not expose the inverter to rain, snow, spray or dust. To reduce the risk of fire hazard, do not cover or obstruct the ventilation openings and do not install the inverter in a zero-clearance compartment.
- 1-1-2. To avoid the risk of fire and electric shock, make sure that the existing wiring is in good electrical condition and that the wire size is not undersized.
Do not operate the inverter with damaged or substandard wiring.
- 1-1-3. Depending on the use, the AC output of the inverter may require user installed breaker or fusing. For telecom use, a GFCI has not been provided. The inverter incorporates standard AC short circuit protection.
- 1-1-4. The following precautions should be taken when working on the inverter:
 - Remove watches, rings, or other metal objects.
 - Use tools with insulated handles.
 - Wear rubber gloves and boots.

1-2. Other Safety Notes

- 1-2-1. Upon receipt, examine the shipment box for damage. Notify the carrier immediately before opening, if damage is evident.
- 1-2-2. Do not operate near water or in excessive humidity.
- 1-2-3. Do not open or disassemble the inverter, warranty may be voided.
- 1-2-4. The DC side connections should be firm and tight
- 1-2-5. Grounding: Reliable grounding of rack-mounted equipment should be maintained.
- 1-2-6. Do not drop a metal tool on the battery. The resulting spark or short-circuit on the battery or on the other electrical part may cause an explosion.

- 1-2-7. Install the inverter in a well-ventilated area. Do not block the front air vents, or the rear air exhausts of the unit.
- 1-2-8. Wiring: Adequate input power must be supplied to the inverter for proper use; correct wiring sizes must be ensured.
- 1-2-9. Mount the inverter such that the fan axis is horizontal
- 1-2-10. Do not operate the inverter close to combustible gas or open fire.
- 1-2-11. Do not operate appliances that may feed power back into the Inverter.
- 1-2-12. Temperature: The inverter should be operated in an ambient temperature range of 0°C to 50 °C or else the output efficiency may be affected. Air flow to the inverter must not be restricted

2. Functional Characteristics - Introduction


2-1. System

The unit is a highly reliable DC-AC inverter system, designed with advanced power electronic and microprocessor technology offering the following features:

- The inverter is equipped with a self diagnosis microprocessor that is able to identify and show all failure messages on the LED/LCD display with associated visual/audio alarm(s).
- 1U height x 19" width x 13.6" depth, 19" rack mountable.
- Pure sine wave output (THD < 3%) to operate higher-end electronic equipment.
- Built in 12A rated transfer switch.
- Speeds up transfer time as a result of synchronized operation with the AC source at all times that allows the transfer to be interruption-free for sensitive equipment.
- Intelligent software for power management
- Hard-wire and Dual AC outlets connection model option.
- Loading and temperature controlled cooling fan.
- Fan aging, failure, disconnection and blockage alarm.
- Selectable Bypass/Inverter modes
- Local and remote management and control.
- RS-232 communication.

- Dry contact terminal.
- Efficiency >90%. (Full linear load at 220 VAC Output)
- Advanced Protection Features:
 - Input over/under voltage protection.
 - Internal over temperature protection.
 - Input reverse polarity protection (Fuse).
 - Output overload protection.
 - Output short circuit protection
 - AC input short circuit protection: Breaker (6 Amp or 12 Amp)

2-2. Block Diagram



The inverter features IGBT technology which minimizes weight and dimension while enhancing output short circuit reliability and overload capacity.

AC output voltage is provided in one of the two following modes:

- 1). From DC to AC Inverter Mode: (On-line Mode)
- 2). From AC Input Bypass Mode: (Off-line Mode)

Either mode is front panel programmable.

In the first option, **Off-line mode**, AC output power will be supplied through the AC bypass mode in its normal operation. Upon AC input failure, output power will be diverted through the DC to AC Inverter Mode. Once AC mains are restored, the unit will revert from the Inverter Mode to the Bypass Mode.

In the second option, **On-line mode**, AC output power will be provided directly by the inverter from the DC source. Should the DC source or inverter fail, the system will transfer its output power through the bypass mode. Once the DC power source is restored, the system will revert to the inverter mode.

SR Series Inverter

2-3. Electrical Performance


| Electrical | Specification | Model No. | | | |
|------------------------------|--------------------------------|--|-----------------------------|------------------------------|-----------------------------|
| | | SR1000-124 | SR1000-148 | SR1000-224 | SR1000-248 |
| Input Characteristics | Item | SR1000-124 | SR1000-148 | SR1000-224 | SR1000-248 |
| | Voltage | 24 VDC | 48 VDC | 24 VDC | 48 VDC |
| | Input Over-Voltage Protection | 30~34 VDC (User-selectable) | 60~68 VDC (User-selectable) | 30~34 VDC (User-selectable) | 60~68 VDC (User-selectable) |
| | Input Under-Voltage Protection | 18~22 VDC (User-selectable) | 36~44 VDC (User-selectable) | 18~22 VDC (User-selectable) | 36~44 VDC (User-selectable) |
| | No Load Current | 0.68 A | 0.44 A | 0.6 A | 0.35 A |
| Output Characteristics | Continuous Output Power | 1000 W | | | |
| | Maximum output Power (3 Min) | 1150 W | | | |
| | Surge Power | 2000 W | | | |
| | Frequency | 50 / 60 Hz +/- 0.05 % | | | |
| | Output Voltage | 97~123 VAC(User-selectable) | | 194~246 VAC(User-selectable) | |
| | Efficiency (Full Load) | 87% | 88% | 90% | 91% |
| | Short-Circuit Protection | Yes , Ipk | | | |
| | Output Waveform | Pure Sine Wave (THD < 3%) | | | |
| Signal and Control | LCD Panel | 2 Lines LCD Panel with keypad for navigation | | | |
| | LED Indicator | Red/Orange/Green LED | | | |
| | Dry Contact Terminal | By a relay | | | |
| | Remote Control Terminal | Controls the inverter ON / OFF operation | | | |
| Protection | Input Protection | Over/Under Voltage, Reverse Polarity (Internal Fuse) | | | |
| | AC Output Protection | Short-Circuit, Overload | | | |
| | AC Input Protection | 12 Amp Circuit Breaker | | 6 Amp Circuit Breaker | |
| | Temperature protection | Shutdown (Internal temperature $\geq 65^{\circ}\text{C}$) | | | |
| Transfer Relay | Relay Specification | 12 Amp / 250 VAC | | | |
| | Bypass Relay | On Line/Off Line (Haphazard, Normal, Exact) selectable | | | |
| | Switching Time | From AC bypass mode (Off-line Mode) : $\leq 9\text{mS}$ From DC to AC inverter mode (On-line Mode): $\leq 7\text{mS}$ | | | |
| Operating Temperature | Full Load | 0°C ~ 50°C | | | |
| | Storage | -30°C~70°C | | | |
| Fan Operation and Indication | Failure Indication | Buzzer alarm and dry contact | | | |
| | Switches On when: | Temperature $\geq 55^{\circ}\text{C}$ or Load $\geq 30\%$ | | | |
| | Switches Off When: | Temperature $\leq 45^{\circ}\text{C}$ and Load $\leq 20\%$ | | | |
| Mechanical Specifications | Size (W X H X D) | 19"x1.71"x13.6"(482.6mmX43.5mmX345mm) | | | |
| | Weight | 5.8 Kgs (12.7 Lbs) | | | |
| Safety and EMI / EMC | Safety Standards | Meets UL60950 | Meets EN60950-1 | | |

SR Series Inverter

| | | | |
|--|----------------------|--------------------|---|
| | EMC Standards | FCC Class B | EN55022: 1998+A1: 2000+A2: 2003 Class B EN55024: 1997+A1: 2001+a2: 2003 EN61000-3-2: 2006 Class A EN61000-3-3: 1995+A1: 2001 |
|--|----------------------|--------------------|---|

Note: The specifications are subject to change without notice.

2-4. Mechanical Drawings




SR Series Inverter Ordering Information

| Model Number | Input Voltage | Output Voltage Nominal | Output Voltage Range | Frequency Range |
|--------------|---------------|------------------------|----------------------|-----------------|
| SR1000-124 | 24 VDC | 110 VAC | 100~120 VAC | 47~63 Hz |
| SR1000-224 | 24 VDC | 230 VAC | 200~240 VAC | 47~63 Hz |
| SR1000-148 | 48 VDC | 110 VAC | 100~120 VAC | 47~63 Hz |
| SR1000-248 | 48 VDC | 230 VAC | 200~240 VAC | 47~63 Hz |

3. Installation and Maintenance

3-1. Rear Panel

REAR PANEL VIEW




3-1-1. AC Input Breaker:

↑ Correct spelling of socket

The AC input circuit breaker protects the unit from overload. When an overload condition occurs, the circuit breaker trips and disconnects the AC grid power input. To reset it, push the circuit breaker button. The cause of tripping should be ascertained and corrected before the unit is reset .

3-1-2. Hard-wire Installation (AC wiring connections):

AC input and AC output terminal



Connect AC output and AC input wiring to the Inverter terminals.


Please use the following information as your reference:

SR Series Inverter

| Terminal | | Wire color | Wire length / gauge |
|----------------------|-------------|----------------------------------|--|
| AC OUTPUT | Line (L) | Black (120 VAC), Brown (230 VAC) | Within 16 feet / AWG# 14~16 26~32 feet / AWG# 12~14 |
| | Neutral (N) | White (120 VAC), Blue (230 VAC) | |
| AC INPUT | Line (L) | Black (120 VAC), Brown (230 VAC) | |
| | Neutral (N) | White (120 VAC), Blue (230 VAC) | |
| Chassis Ground or FG | | Green / Yellow or Bare copper | |

Note. Please double check and review all the connections to ensure that the wires are connected to the correct terminals and that the connections are tight.

3-1-3. AC output socket:




3-1-4. Chassis Ground: Must be connected to earth ground prior to making any other connections to the equipment.

3-1-5. RS-232: Serial port for monitoring and control through computer interface


SR Series Inverter

3-1-6. Remote control and Dry contact terminal:



Remote Control Terminals:

- 1). Before installing the inverter, ensure that the main switch is "OFF".
- 2). Before using the remote function, ensure that the main switch is pressed towards "REMOTE".
- 3). Ensure that the remote contacts are off.
- 4). Use 20 ~ 24 #AWG wire to connect the remote control terminals.
- 5). Remote control ON/OFF inverter setup status:



NOTE: At one time, only one remote function should be used to control the inverter. The maximum voltage value is the same as input DC voltage.

SR Series Inverter

■ Dry Contact Terminals:

Dry contact terminals may be connected to a Form C relay for “FAULT” indication. When “FAULT” occurs, the relay switches.

NOTE: Fault conditions include Input under/over voltage, Output Short Circuit, Over Temperature, Over-load and Fan Failure.

Specifications of the Relay

| Maximum Voltage | Load | Contact Rating | | Number of operations | Operating/Storage Temperature |
|-----------------|-----------|----------------|------|----------------------|-------------------------------|
| | | N.O. | N.C. | | |
| 240 VAC | Resistive | 16 A | — | 100,000 | -30°C~70°C |
| 240 VAC | Resistive | — | 8 A | — | |
| 30 VDC | Resistive | 16 A | — | — | |
| 30 VDC | Resistive | — | 8 A | — | |

| Dry Contact Terminal | RELAY |
|----------------------|--------------------------|
| COM. | Common contact |
| N.C. | Normally closed contact. |
| N.O. | Normally open contact. |

3-1-7. DC Input Connection:

Follow the instructions to connect the battery cables to the DC input terminals of the inverter. The cables should be as short as possible (less than 6 feet / 1.8 meters ideally) so that they can handle the required current in accordance with the Electrical Codes and Regulations. The size of the cable should be thick enough to limit the voltage drop to less than 2% when carrying the maximum input current to prevent frequent low-input voltage warnings and shutdown. UVP (Under Voltage Protection) warning may result if there is excessive voltage drop across the DC cables between the batteries and the inverter. Increasing your DC cable size will help improve the situation.

Batteries are capable of providing very large currents in case of short circuit. In case there is a short circuit in the cable run between the batteries and the input terminals of the inverter, it will result in overheating / melting of the cables and consequent risk of fire and injury. To prevent possibility of this hazard, use Very Fast Acting DC Fuse in line with the positive cable. The fuse should be as close to the positive battery terminal as possible. Use Bussmann ANN series fuses (will also require Fuse Block 4164) or equivalent

The following sizes of cables and fuses are recommended for up to 6 ft. distance between the batteries and the inverter. (Applies to both 120 VAC and 230 VAC versions):

| Model No | Wire AWG | Inline Fuse |
|------------------|----------|-------------|
| SR1000-124 / 224 | # 4 | 80 A |
| SR1000-148 / 248 | # 6 | 40 A |


- Connect DC input terminals to 24V / 48V battery or other DC power source. [+] is positive, [-] is negative. Reverse polarity connection can blow the internal fuse and may damage the inverter permanently.




WARNING!

Make sure that all the DC connections are tight (torque to 9 – 10 ft-lbs, 11.7 – 13 Nm). Loose connections could result in overheating and can be a potential hazard.


SR Series Inverter



WARNING!




The recommended inline fuse should be installed as close to the battery positive terminal as possible. Failure to use a fuse on the "+" cable running between the inverter and battery may cause damage to the cable / inverter and will void warranty.



3-2. Front Panel

FRONT PANEL VIEW



3-2-1. Main Switch: These are buttons for turning on, turning off and remote.

3-2-2. LED's Indicators: See details in Section 5-1.

3-2-3. LCD Display Selection Buttons:

Data pertaining to the DC input voltage, AC output voltage, AC output frequency, AC output current, etc. and system status can be shown sequentially on the LCD display by pressing these buttons. Please refer to chapter 5 for more information.

3-2-4. FAN ventilation grille (1)~(3) : The fans behind the ventilation grilles provide cooling. **DOT NOT** obstruct these vents!

3-3. Maintenance

3-3-1. Make sure that the fan vents are not blocked.

3-3-2. Use a vacuum cleaner to remove any dust from the fan area.

3-3-3. When cleaning the case or front panel, use a soft, dry cloth, only. If the case or front panel is very dirty, use a neutral, non-abrasive detergent. Do not use alcohol or ammonia based solutions.

3-3-4. Regular service and relocation of the inverter should be performed by a qualified service technician.

3-3-5. Avoid spilling liquid on the inverter.

4. Operation:

4-1. Connecting the input power

Before making the DC input side connections, the main switch must be "OFF".

4-2. Connecting the loads

■ Calculate the total power consumption(W) of the output load. Make sure that the total power consumption does not exceed the rated load.

■ Should the total load exceed the rated capacity of the inverter, remove the non-critical loads until the rated total has been reached.

4-3. Inverter Operation

- Set the power switch to the “ON” position. The buzzer will sound “beep beep”. The inverter will carry out self-diagnosis and the LED’s will change colors. At the same time the LCD will display ”SR-1000 INVERTER INITIALIATION..”.

Finally, the buzzer will sound another “beep” and the “INVERTER” and status LED’s will turn “Green” . The LCD Display will display “Vi, Vo, FQ, Io”. The inverter will start operating normally.
- Set the power switch to the “OFF” position. The inverter stops and all the lights that are on will go off.


4-4. Protections Features

| Model | DC Input (VDC) | | | | | Over Temperature Protection | | | |
|-------|----------------|---------|---------------------|---------------|---------|-----------------------------|---------|-----------|---------|
| | Over Voltage | | Under Voltage Alarm | Under Voltage | | INTERIOR | | HEAT SINK | |
| | Shut-down | Restart | | Shut-down | Restart | Shut-down | Restart | Shut-down | Restart |
| 24 V | 30.1~34.1 | 28~32 | 19~23 | 18.1~22.1 | 23~27 | 65°C | 45°C | 105°C | 75°C |
| 48 V | 60.1~68.1 | 56~64 | 38~46 | 36.1~44.1 | 46~54 | | | | |

5. Front LCD Panel – Display & Setup

5-1. LCD Panel Indications

5-1-1. Set the Power Switch to the “ON” position. The inverter starts working normally. The inverter will be operating in normal condition when either of the following messages are displayed on the LCD screen:



SR Series Inverter

5-1-2. LED Indications:

AC GRID: Displays AC input status.

| AC Input | LED Status |
|--|------------|
| AC input and DC-AC inverter output are NOT synchronous | ORANGE |
| AC input and DC-AC Inverter output are synchronous | GREEN |
| AC input OFF | OFF |

Note. Synchronous means that the grid AC input frequency and DC-AC inverter output frequency or phase are the same (See details in Section 5-3-3).

INVERTER: Displays DC-AC inverter status.

| DC-AC Inverter | LED Status |
|----------------|------------|
| Power OK | GREEN |
| Power not good | RED |

BYPASS: Displays Transfer Switch status.

| BYPASS | LED Status | AC OUTPUT (LOAD) |
|---|------------|------------------|
| From DC-AC inverter (On-line Mode) | ORANGE | AC INPUT |
| | OFF | DC-AC Inverter |
| From AC input bypass (Off-line Mode) | GREEN | AC INPUT |
| | OFF | DC-AC Inverter |

ALARM: Displays status of the Failure Alarm

| ALARM | LED Status |
|---|------------|
| Over/Under Alarm /FAN Alarm | ORANGE |
| Set alarm in the inverter to operate normally | OFF |

NOTE. For instructions on setting the alarm, see details in Section 5-3.

SR Series Inverter

5-1-3. LCD Display Selection Buttons:

Function of Various Keys :



Function <Up>: You can use the “up” button to scroll through the menus.



Function <Down>: You can use the “Down” button to scroll through the menus.



Function <Page Up>: You can use the “Page Up” button to scroll through the menus.



Function <Page Down>: You can use the “Page Down” button to scroll through the menus.

Function <Enter Setup Menu>: Press the button longer than 2 seconds. The inverter will change to “Setup Menu Mode” which appears on the LCD screen for the user to set functions.


Function <Enter>: Confirms a selection or value.

5-1-4. **LCD Display:** Displays inverter’s operational status.

5-2. Startup Sequence and Standby Status

5-2-1. Set the power switch to "ON" to power up the inverter. The display shows "SR-1000 INVERTER INITIALIZATION", then checks the inverter.


Status flow is as follows:




5-3. Setup Menu - Operation and Instructions

Entering Setup Menu:



Press  Button longer than 2 seconds. The inverter enters the Setup Menu consisting of three layers: (1) Select Menu Heading, (2) Select Menu Item (Function Code), (3) Set Value:



5-3-1. User interface (Select Menu):

0). **LCD Contrast:** Sets LCD screen contrast.

Default=50%

Setting Range= 0%~100%

1). **LCD Auto-off:** Sets LCD auto off timer.

Default=120 seconds.

Setting Range= Disable~250 seconds.

2). **RS232 Baud-rate:** Sets standard RS-232 Baud-rate.

Default=4800

Setting Range= 1200/2400/4800/9600/19200

3). **Buzzer Setting:** Sets the internal buzzer sound ON/OFF.

When setting, the LCD screen displays

Buzzer "ON", Buzzer "OFF".

Default=MSG, Alert, SHDN

Setting Range= Disable / Shutdown / Alert

/ Alert, SHDN / Message

/ Message, SHDN / Message, Alert

/ MSG, Alert, SHDN

| MENU | STATUS | BUZZER |
|----------|--|--------|
| Message | Power ON or Push Keypad | ON |
| Alert | FAN Fail or UV Alarm or Overload Alarm | ON |
| Shutdown | OVP or UVP or OLP or OTP | ON |
| Disable | Any | OFF |

- 4). **Alert Setup:** When alert occurs, the internal Dry Contact Relay will open/close. (See details in Section 3-1-6)

Default = Alert, SHDN

Setting Range = Disable / Shutdown / Alert / Alert, SHDN

| MENU | STATUS | RELAY |
|----------|--|-------|
| Alert | FAN Fail or UV Alarm or Overload Alarm | ON |
| Shutdown | OVP or UVP or OLP or OTP | ON |
| Disable | Any | OFF |

5-3-2. I/P Parameter (Select Menu):

- 6). **OVP Setting:** Sets the Over Voltage Protection (OVP) and shutdown.

Default = 32 VDC for 24 V Model, 64 VDC for 48 V Model

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 24 V | 30 VDC ~ 34 VDC |
| 48 V | 60 VDC ~68 VDC |

- 7). **OVP Recovery:** When the DC input voltage is higher than the OVP setting, the inverter shuts-down. Once the input voltage falls below the set OVP value, the inverter will automatically restart.

Default = 30 VDC for 24 V Model, 60 VDC for 48 V Model

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 24 V | 28 VDC ~ 32 VDC |
| 48 V | 56 VDC ~ 64 VDC |

- 8). **UVP Setting:** Setting the inverter's Under-Voltage Protection (UVP) and Shutdown.

Default = 20 VDC for 24 V Model, 40 VDC for 48 V Model

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 24 V | 18 VDC ~22 VDC |
| 48 V | 36 VDC ~ 44 VDC |

SR Series Inverter

- 9). **UVP Recovery:** When the DC input voltage is below the set UVP value the inverter shuts-down. Once the input voltage rises above the set UVP value, the inverter will automatically restart.

Default=25 VDC for 24 V Model, 50 VDC for 48 V Model

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 24 V | 23 VDC ~ 27 VDC |
| 48 V | 46 VDC ~ 54 VDC |

- 10). **UV Alarm:** Sets Under Voltage (UV) alarm. When the input voltage is lower than the set value, the unit will sound “beep” to remind that the unit is going to shutdown. At the meantime, the contact in the internal Dry Contact Relay will open / close (See details in Section 3-1-6).

Default = 21 VDC for 24 V Model, 42 VDC for 48 V Model

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 24 V | 19 VDC ~ 23 VDC |
| 48 V | 38 VDC ~ 46 VDC |

NOTE. The value of voltage set for the “UV Alarm” should be equal to or higher than the value set for “UVP” or else the unit will shutdown without any audible warning.

5-3-3. O/P Parameters:

- 11). **O/P Voltage:** Sets the inverter output voltage.

Default = 110 VAC for 110 V Model, 230 VAC for 220 V Model

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 110 V | 97 VAC ~ 123 VAC |
| 220 V | 194 VAC ~ 246 VAC |

- 12). **O/P Frequency:** Sets the inverter output frequency.

Default = 60Hz for 110 V Model, 50Hz for 220 V Model.

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 110 V | 47 Hz ~ 63 Hz |
| 220 V | 47 Hz ~ 63 Hz |

- 13). **Sync Frequency:** Sets the AC output synchronous frequency.

Example: DC to AC inverter = 230 VAC / 50Hz

User setting Value = 7Hz

When the AC input (GRID) “Frequency” is within the range of 43 Hz~57 Hz, the internal transfer relay will

SR Series Inverter


operate normally . When the “Frequency” of the incoming grid power is less than 43 Hz. or more than 58 Hz., the internal transfer relay will de-energize (See details in Section 2-2)

Default = 0.1Hz ~ 7Hz.

| Model | SETTING VALUE RANGE |
|-------|---------------------|
| 110 V | 0.1 Hz ~7 Hz |
| 230 V | 0.1 Hz ~ 7 Hz |

- 14). **Bypass Relay:** The setup is provided in one of the following two ways:
 On line Mode or Off Line Mode (Exact, Normal, Haphazard)
Default = Normal (Off line).

| MODE | MENU | Transfer Relay Switching Feature |
|---|-----------|--|
| OFF LINE (See details in Section 5-3) | Exact | The transfer relay will switch “ON” or “OFF” based on conformance to the Sync Frequency window that has been set (Function Code 13) |
| | Normal | The transfer relay will be “ON” if AC input (Grid) power is available. The DC-AC inverter will remain synchronized with the incoming AC power (Grid). The relay will NOT switch off if the grid frequency is beyond the range set under Sync Frequency window (Function Code 13) |
| | Haphazard | The transfer relay will switch “ON” or “OFF”. Conformance to phase and frequency synchronization will not be considered |
| ON LINE | ----- | (See details in Section 5-3) |



15). **Overload Alarm:** Sets the overload alarm. When the output power is higher than the set value, the unit will sound “beep” to remind that the unit is going to shutdown. At the same time, the internal Dry Contact Relay will open/close (See details in Section 3-1-6).


Default = 100%

Setting range = 50%~110%

6. RS-232 Communication and Operation

6-1. Operation of RS-232 Serial Port:


6-1-1. This unit uses a standard 9-Pole D connector and three of the RS232 signal lines:



| Signal description | PIN |
|--------------------|-----|
| N.C | 1 |
| RXD | 2 |
| TXD | 3 |
| DTR | 4 |
| GND | 5 |
| DSR | 6 |
| RTS | 7 |
| CTS | 8 |
| N.C | 9 |

SR Series Inverter

6-1-2. The connection between this unit and the computer is as follows:



6-1-3. The RS232 interface of this unit employs ASCII code to implement the asynchronous serial transmission control.

The byte structure is START-BIP – 8 BIT DATA-STOP BIT.

Baud rate: 1200/2400/4800/9600/19200 (See details in Section 5-3-1).

6-1-4. Coupled with PC software application port. Operation is as detailed in Section 6-2.

6-2. Interface Commands:

The buffer size used for the RS232 port is 12-byte. This unit will ignore all bytes more than this value. During transmission, this unit will indicate it is ready to receive data from computer by this DTR line. A computer has to check the DTR line before sending any information to this unit. This unit is normally always ready to receive data while operating. When a LF character (ASCII code 0AH) is received, this unit would finish the receiving by clearing the DTR status and begin to interpret the received information. The unit would execute the received command (AND/OR data) if it is correct. Irrespective of whether the command is accepted or not, the unit will always send back a response signal to the computer and set DTR to ready for receiving more incoming information.

6-2-1. The Baud-rate of the RS232 interface can be set with the help of the Setup Menu (See details in Section 5-3-1).

Note. You have to reset the unit after adjustment to activate the new setting.

6-3. Example of the RS232 Operation:

6-3-1. RS232 command:

Command format:

This unit uses high-level language commands with a CR (0DH) and LF (0AH) as the end of the command.

The system would interpret and execute the command only after these two characters are received.

After the unit execute the command, it would send a response string to the computer.

The response string is as follows:

= > CR LF: Command executed successfully

? > CR LF: Command error, not accepted

! > CR LF: Command correct but execution error (e.g. parameters out of range).

If the command needs any information from the unit, the unit would send the information back to the computer (with CR and LF) and then send the response string to the computer.

6-3-2. Command format:

This unit supports the following command format.

There should always be a CR (0DH) and a LF (0AH) appended to the command while sending the command to this unit.

1). Command to switch the Power ON/OFF:

Format: Power <value>

Example: A space (ASCII code 20H) is needed between Power and <value>.

<value> can be one of the following.

“0”: Power off

“1”: Power on

2). Command to query the Output Frequency:

Format: FRQ?

After “Enter”, the unit’s “Output Frequency” appears on the PC screen.

3). Command to query the Output Voltage

Format: VOL?

After “Enter”, the unit’s “Output Voltage” appears on the PC screen.

SR Series Inverter

- 4). Command to query the Output Current

Format: AMP?

After “Enter”, the unit’s “Output Current” appears on the PC screen.

- 5). Command to query the Input Battery Voltage:

Format: BAT?

After “Enter”, the unit’s “Input Voltage” appears on the PC screen.

6-3-3. Command for accessing Setup Menus and adjusting values:

- 1). Selecting the Setup Menus with the help of Function Codes:

Format: FUNC <Function Code>

After “Enter”, the Setup Menu for the Function Code will be called.

The <Function Code> = 0~17, as follows:

| <Function Code> | Setup Menu | <Function Code> | Setup Menu |
|-----------------|-----------------|-----------------|----------------|
| 0 | LCD Contrast | 9 | UVP Recovery |
| 1 | LCD Auto-off | 10 | UV Alarm |
| 2 | RS232 Baud-rate | 11 | O/P Voltage |
| 3 | Buzzer Setting | 12 | O/P Frequency |
| 4 | Alert Setting | 13 | Sync Frequency |
| 5 | NOT USED | 14 | Bypass Relay |
| 6 | OVP Setting | 15 | Overload Alarm |
| 7 | OVP Recovery | 16 | NOT USED |
| 8 | UVP Setting | 17 | NOT USED |

- 2). Command to query the Functions No:

Format: FUNC?

After “Enter”, the unit’s “Function Code” appears on the PC screen.

- 3). Command to query the set value of the Function:

Format: SETT?

After “Enter”, the existing set value of the function appears on the PC screen.

- 4). Command to set or adjust the value of the Function:

Format: SETT <value>

After “Enter”, the new value of the Function is set

Choose the <value> of the function as follows:

FUNC 0: LCD Contrast

| Setup Menu | SETT <value> |
|--------------|--------------|
| LCD Contrast | 0~100 |

SR Series Inverter

FUNC 1: LCD Auto-off

| Setup Menu | SETT <value> |
|--------------|--------------|
| LCD Auto-off | Disable~250 |

FUNC 2: RS232 Baud rate

| Setup Menu | SETT <value> | Baud rate |
|---------------------|--------------|-----------|
| RS-232 Baud rate | 0 | 1200 |
| | 1 | 2400 |
| | 2 | 4800 |
| | 3 | 9600 |
| | 4 | 19200 |

FUNC 3: Buzzer Setting

| Setup Menu | SETT <value> | Buzzer (Beep sound) |
|----------------|--------------|---------------------|
| Buzzer Setting | 0 | Disable |
| | 1 | Shutdown |
| | 2 | Alert |
| | 3 | Alert , SHDN |
| | 4 | Message |
| | 5 | Message , SHDN |
| | 6 | Message , Alert |
| | 7 | Msg , Alert , SHDN |

FUNC 4: Alert Setting

| Setup Menu | SETT <value> | Alert |
|---------------|--------------|--------------|
| Alert Setting | 0 | Disable |
| | 1 | Shutdown |
| | 2 | Alert |
| | 3 | Alert , SHDW |

FUNC 6: OVP Setting

| Setup Menu | SETT <value> | Model |
|-------------|--------------|------------|
| OVP Setting | 30~34 | SR1000-124 |
| | | SR1000-224 |
| | 60~68 | SR1000-148 |
| | | SR1000-248 |

SR Series Inverter

FUNC 7: OVP Recovery

| Setup Menu | SETT <value> | Model |
|--------------|--------------|------------|
| OVP Recovery | 28~32 | SR1000-124 |
| | | SR1000-224 |
| | 56~64 | SR1000-148 |
| | | SR1000-248 |

FUNC 8: UVP Setting

| Setup Menu | SETT <value> | Model |
|-------------|--------------|------------|
| UVP Setting | 18~22 | SR1000-124 |
| | | SR1000-224 |
| | 36~44 | SR1000-148 |
| | | SR1000-248 |

FUNC 9: UVP Recovery

| Setup Menu | SETT <value> | Model |
|--------------|--------------|------------|
| UVP Recovery | 23~27 | SR1000-124 |
| | | SR1000-224 |
| | 46~54 | SR1000-148 |
| | | SR1000-248 |

FUNC 10: UV Alarm

| Setup Menu | SETT <value> | Model |
|------------|--------------|------------|
| UV Alert | 19~23 | SR1000-124 |
| | | SR1000-224 |
| | 38~46 | SR1000-148 |
| | | SR1000-248 |

FUNC 11: O/P Voltage

| Setup Menu | SETT <value> | Model |
|-------------|--------------|------------|
| O/P Voltage | 97~123 | SR1000-124 |
| | | SR1000-148 |
| | 194~246 | SR1000-224 |
| | | SR1000-248 |

FUNC 12: O/P Frequency

| Setup Menu | SETT <value> |
|---------------|--------------|
| O/P Frequency | 47~63 |

FUNC 13: Sync Frequency

| Setup Menu | SETT <value> |
|----------------|--------------|
| Sync Frequency | 0.1~7 |

FUNC 14: Bypass Relay

| Setup Menu | SETT <value> | MODE |
|--------------|--------------|---------------------|
| Bypass Relay | 0 | ON LINE |
| | 1 | Haphazard(OFF LINE) |
| | 2 | Normal(OFF LINE) |
| | 3 | Exact(OFF LINE) |

FUNC 15: Overload Alarm

| Setup Menu | SETT <value> |
|----------------|--------------|
| Overload Alarm | 50~110 |

7. Information

7-1. Troubleshooting



WARNING

Do not open or disassemble the SR series Inverter. Attempting to service the unit may cause risk of electrical shock or fire.

| Problems and Symptoms | Possible Cause | Solutions |
|--------------------------------------|---|--|
| <i>No AC Power "Output"</i> | | |
| a. LCD Panel Display "OLP Shutdown". | Short circuit ,wiring error . over loading. | Check AC wiring for short circuit . Reduce load. |
| b. LCD Panel Display "OVP Shutdown" | Over input voltage (OVP) | Check input voltage Reduce input voltage |
| c. LCD Panel Display "UVP Shutdown" | Low input voltage. (UVP) | Recharge battery. Check connections and cables. |
| d. LCD Panel Display "OTP shutdown" | Thermal shutdown. (OTP) | Improve ventilation. Make sure ventilation grilles / slots of the inverter are not obstructed. Lower ambient temperature. |

7-2. Warranty

We guarantee this product against defects in materials and workmanship for a period of 24 months from the date of purchase and will repair or replace any defective power inverters if you directly returned them to us with postage paid.

Please note that Cotek is only responsible for ensuring our products are operational before delivering. This warranty will be considered void if the unit has been misused, altered, or accidentally damaged. Cotek is not liable for anything that occurs as a result of the user's fault.

8. Appendices

No. 33, Rong Hsin Rd., Pa Teh City, Tao Yuan County, Taiwan

Phone : 886-3-3661581 FAX : 886-3-3676029

E-mail : sales@cotek.com.tw http : // www.cotek.com.tw

2007.05